

PINNACLE AT TUTWILER FARM

Highway 11 Pinnacle Square, Trussville, AL 35173

MAIN LEVEL

LEASE PLAN

General Notes:

1 This exhibit is diagramatic. It is intended only for the purpose of indicating the location of the demised premises within the project. It does not purport to show the exact or final location of columns, walls, stairways or other Architectural, Structural, Mechanical or Electrical elements. The landlord reserves the right to eliminate, to add and to make changes to the sizes and/or locations of such elements as may be required from time to time.

2 Dimensions and areas, where indicated for individual premises, are measured under the following
A.) Centerline to Centerline of demising walls
B.) Exterior face of all exterior walls
C.) To the exterior face of any corridor or bldg. service wall

3 The tenant, the Tenant's Architect & the Tenant's contractor have complete and total responsibility to verify all conditions and dimensions, and all utility connection points, in the field before starting any design, documentation & construction work.

JONES LANG LASALLE.

3344 Peachtree Road, N.E.
Suite 1200
Atlanta, Georgia 30326

REVISION DATE

11/1/09